

GPIO ① ②

3V3	5V	5V	GND	P06	TXD	GND	RXD	P37	GND	P136	GND	P03	P133	P65	GND	MO1	MI1	P127	CLK1	CS1	GND	P139	P66	GND	P01	P02	P04	P39	P134	P38	GND	P40	

**QUECTEL**

QuecPython 2332.

**Board For EC200U/A-XX**

- SDA
- SCL
- RST
- DP0
- DN0
- CP
- CN
- DP1
- DN1

- DRX
- DTX

Powered by QuecPython

- IO0 TP28 R59 TP27
- CS TP26 R58 TP25
- CLK TP24 R57 TP24

- ⚡ SCK2 R79
- ⚡ SCK1 R53

- ⚡ P01 R44
- ⚡ P05 R47
- ⚡ PWR R26

USB

PWK RST BOOT

SW3 SW4 SW5

PWK_AUTO	VDD_EXT	MODULE_EN	SD_EN	GNSS_EN

**C4-P01**

Made in China

NO:EC200U/A-XX\_20230807\_0026

+ MIC - - SPK +

JP10 JP4

LTE


GNSS

DIV/WIFI/BLE



ET

V1.2

SCK GND  
 TP44 TP45 R40 TP48  
 3V8 TP40 PWDN  
 SDA0 TP46 TP49  
 SCL0 TP47 Cam\_VDD




SD




TP8 DAT3  
 TP22 DAT2  
 TP12 DAT1  
 TP11 DAT0  
 TP10 CLK  
 TP9 CMD  
 TP13 VDD


TP33 KO5  
 TP34 TP32 KO0  
 TP29 TP29 KO1  
 TP31 TP31 KO2  
 TP30 TP30 KO3



USB\_ON/OFF





CLK2 DAT2



RST2 VDD2 TP20 TP17

SIM1

TP14 VDD  
 TP18 DAT  
 TP16 CLK  
 TP15 RST



R7, R8, R54