


SCK GND
 TP44 TP45 R40 TP48
 3V8 TP40 PWDN
 SDA0 TP46 TP50
 SCL0 TP47 Cam_VDD







TP49 SD_VDD


SD 2.0



IR10
 R9 TP8 DAT3
 IR16 TP22 DAT2
 IR14 TP12 DAT1
 IR12 TP11 DAT0
 R11 TP10 CLK
 TP9 CMD
 TP13 VDD




USB_ON/OFF




CLK2 DAT2
TP21 TP19

SIM2



RST2 VDD2 TP20 TP17 Q3



SIM1

TP14 VDD
 TP18 DAT
 TP16 CLK
 TP15 RST

